

0170893en	006
0809	

Indirect-fired Air Heaters

Cub 200/300/300 HD



OPERATOR'S MANUAL



1 Foreword**CALIFORNIA****Proposition 65 Warning:**

Engine exhaust, some of its constituents, and certain vehicle components, contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

This manual provides information and procedures to safely operate and maintain this Wacker Neuson model. For your own safety and protection from injury, carefully read, understand and observe the safety instructions described in this manual.

Keep this manual or a copy of it with the machine. If you lose this manual or need an additional copy, please contact Wacker Neuson Corporation. This machine is built with user safety in mind; however, it can present hazards if improperly operated and serviced. Follow operating instructions carefully! If you have questions about operating or servicing this equipment, please contact Wacker Neuson Corporation.

The information contained in this manual was based on machines in production at the time of publication. Wacker Neuson Corporation reserves the right to change any portion of this information without notice.

All rights, especially copying and distribution rights, are reserved.

Copyright 2009 by Wacker Neuson Corporation.

No part of this publication may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission from Wacker Neuson Corporation.

Any type of reproduction or distribution not authorized by Wacker Neuson Corporation represents an infringement of valid copyrights and will be prosecuted. We expressly reserve the right to make technical modifications, even without due notice, which aim at improving our machines or their safety standards.

Foreword

Notes:

1. Foreword	3
2. Safety Information	7
2.1 Operating Safety	7
2.2 Operator Safety while using Combustion Burners	8
2.3 Service Safety	8
2.4 Label Locations	10
2.5 Label Descriptions	11
3. Operation	15
3.1 System Description	15
3.2 Installing the Lift Brackets	15
3.3 System Component Locations	16
3.4 Mounting the Handle and Base Assembly	17
3.5 Machine Location	18
3.6 Suggested Venting	18
3.7 Connecting Power to the Machine	20
3.8 Preliminary Checks	20
3.9 Control Panel	21
3.10 Starting the Machine	22
3.11 Starting the Machine in (Extreme) Cold Weather	23
3.12 Shutting Down the Machine	24
3.13 Using the Remote Thermostat	25
4. Maintenance	27
4.1 Periodic Maintenance Schedule	27
4.2 Removing and Installing the Burner Assembly	28
4.3 Replacing the Burner Nozzle	30
4.4 Replacing the Fuel Filter	31
4.5 Inspecting and Aligning the Burner Electrodes	32
4.6 Inspecting and Cleaning the Cadmium (CAD) Cell	33
4.7 Checking and Adjusting the Fuel Pressure	34
4.8 Cleaning the Fan Blades and Motor	36
4.9 Cleaning the Interior Shell	37
4.10 Inspecting the Flame Head	38

Table of Contents

4.11	Inspecting the Electrical Connections	39
4.12	Fuel Blend Guide	39
4.13	Transporting	40
4.14	List of Abbreviations	41
4.15	Troubleshooting	42
4.16	Cub 200/300 Wiring Schematic	44
4.17	Cub 300 HD Wiring Schematic	44
4.18	Schematic Legend	45

5. Technical Data 47

5.1	Machine Technical Data	47
-----	------------------------------	----

2 Safety Information

This manual contains DANGER, WARNING, CAUTION, *NOTICE*, and NOTE callouts which must be followed to reduce the possibility of personal injury, damage to the equipment, or improper service.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE: Used without the safety alert symbol, **NOTICE** indicates a situation which, if not avoided, could result in property damage.

Note: *Contains additional information important to a procedure.*

2.1 Operating Safety



WARNING

Familiarity and proper training are required for the safe operation of equipment! Equipment operated improperly or by untrained personnel can be dangerous! Read the operating instructions contained in this manual and familiarize yourself with the location and proper use of all controls. Inexperienced operators should receive instruction from someone familiar with the equipment before being allowed to operate the machine.

2.1.1 Be sure the machine is on a firm, level surface and will not tip, roll, slide, or fall while operating.

2.1.2 NEVER start a machine in need of repair.

- 2.1.3 Keep unauthorized personnel, children, and pets away from the machine.
- 2.1.4 Always operate machine with all safety devices and guards in place and in working order. Do not modify or defeat safety devices. Do not operate machine if any safety devices or guards are missing or inoperative.
- 2.1.5 NEVER run the machine indoors or in an enclosed area unless adequate ventilation, through such items as exhaust fans or hoses, is provided and if local and national codes permit. Exhaust from the burner contains poisonous carbon monoxide gas. Exposure to carbon monoxide can cause loss of consciousness and may lead to death.
- 2.1.6 Do not smoke while operating the machine.
- 2.1.7 NEVER run the machine in areas that contain flammable objects, fuels, or products that produce flammable vapors.
- 2.1.8 NEVER connect ductwork between the exhaust outlet port and the supply air inlet port.
- 2.1.9 NEVER block the air inlet or outlet.
- 2.1.10 The installation of this machine must be in accordance with the regulations put forth by all governing bodies having jurisdiction including the Canadian Standard B139.

2.2 Operator Safety while using Combustion Burners

- 2.2.1 Refill the fuel tank in a well-ventilated area.
- 2.2.2 Replace the fuel tank cap after refueling.
- 2.2.3 DO NOT spill fuel when refueling the machine. Clean up spilled fuel immediately.
- 2.2.4 DO NOT smoke when refueling machine.
- 2.2.5 DO NOT refuel a hot or running machine.
- 2.2.6 The machine must be installed by qualified personnel who have read and understand all supplied manuals and instructions.
- 2.2.7 When operating the machine indoors, install a carbon monoxide detector in the work area according to the detector manufacturer's instructions.
- 2.2.8


2.3 Service Safety

**WARNING**

HIGH VOLTAGE! This unit uses high voltage circuits capable of causing serious injury or death. Only a qualified electrician should troubleshoot or repair electrical problems occurring with this equipment.




- 2.3.1 ALWAYS replace the safety devices and guards after repairs and maintenance.
- 2.3.2 Keep the machine clean and labels legible. Replace all missing and hard-to-read labels. Labels provide important operating instructions and warn of dangers and hazards.
- 2.3.3 ALWAYS make sure slings, chains, hooks, ramps, jacks, and other types of lifting devices are attached securely and have enough weight-bearing capacity to lift or hold the machine safely. Always remain aware of the location of other people in the area when lifting the machine.
- 2.3.4 ALWAYS replace or repair electrical components with components that are identical in rating and performance as the original component.
- 2.3.5 Do not use gasoline or other types of fuels or flammable solvents to clean parts, especially in enclosed areas. Fumes from fuels and solvents can become explosive.
- 2.3.6 Always wear protective equipment when servicing the machine. Some machine components may be hot and contain hot fluids.
- 2.3.7 **Notes:**







2.4 Label Locations












ghi_gr006340

2.5 Label Descriptions

Ref.	Label	Label Text
1		<p>Danger! Hazardous voltage. Do not operate without this cover in place. Disconnect and lock out power source before opening panel. Could cause severe injury or death.</p>
2		<p>Warning: Blower can automatically start which can cause serious injury. Disconnect power source before servicing.</p>
3		<p>Warning: Blower can automatically start which can cause serious injury. Disconnect power source before servicing.</p>

Ref.	Label	Label Text
4	 <p>USING A HEATER INDOORS CAN KILL YOU IN MINUTES. HEATER EXHAUST CONTAINS CARBON MONOXIDE, THIS IS A POISON YOU CANNOT SEE OR SMELL. DURING INDOOR OPERATION, VENT EXHAUST GAS OUTDOORS. REFER TO OPERATOR'S MANUAL.</p> <p>DIE ANWENDUNG VON HEIZGERÄTEN IM INNEREN KANN ZUM TOD IN WENIGEN MINUTEN FÜHREN! DAS AUSPUFFROHR GIBT KOHLENMONOXID AUS, EIN GIFT, DAS NICHT GEGEHEN ODER GERUCHEN WERDEN KANN. BEI BETRIEB DRINNEN, DAS ABGAS NACH AUSSEN ENTLÜFTEN. SIEHE BETRIEBSANLEITUNG.</p> <p>EL UTILIZAR UN CALENTADOR EN UN LUGAR CERRADO PUEDE CAUSAR LA MUERTE EN MINUTOS. LOS GASES DE ESCAPE CONTIENEN MONÓXIDO DE CARBONO, ESTE ES UN VENENO QUE SE PUEDE NIVIR, NI OLER. DURANTE LA OPERACIÓN EN INTERIORES, VENTILE EL GAS DE ESCAPE AL EXTERIOR. CONSULTE EL MANUAL DE OPERACIÓN.</p> <p>L'UTILISATION D'UN RÉCHAUFFEUR À L'INTÉRIEUR PEUT VOUS FAIRE MOURIR EN MINUTES. L'ÉCHAPPEMENT CONTIENT LE MONOXYDE DE CARBONE, CECI EST UN TOXIQUE QUE VOUS NE POUVEZ NI VOIR NI SENTIR. EN CAS D'UTILISATION À L'INTÉRIEUR, ÉVACUEZ LES GAZ D'ÉCHAPPEMENT À L'EXTÉRIEUR. SE REPORTER À LA NOTICE D'EMPLOI.</p> <p>0177089</p>	Using a heater indoors can kill you in minutes. Heater exhaust contains carbon monoxide. This is a poison you cannot see or smell. During indoor operation, vent exhaust gas outdoors. Refer to Operator's Manual.
5	 <p>⚠ WARNING ⚠ WARNUNG ⚠ ADVERTENCIA ⚠ AVERTISSEMENT</p>	Warning: Electric shock hazard. Disconnect power before servicing. Read Operator's Manual.
6	 <p>DANGER TO AVOID INJURY FROM MOVING PARTS, SHUT OFF THE EQUIPMENT BEFORE REMOVING THIS COVER.</p>	Danger: To avoid injury from moving parts, shut off the equipment before removing this cover.
7	 <p>⚠ CAUTION DIESEL ⚠ VORSICHT ⚠ PRECAUCION ⚠ PRECAUCION</p>	Caution: This machine uses diesel fuel.
8		Hot surface hazard!
9	 <p>CAUTION VORSICHT PRECAUCION PRECAUCION</p>	Caution: Lift point. Attach lifting device in this location.

Ref.	Label	Label Text
10		Diesel fuel blend guide. This label indicates the recommended fuel blending values for diesel fuel usage.
11		Tie-down point.
12		Machine rating label: This label indicates rating information for the machine.
13		Weight/mass label: This label indicates the total weight of the machine, including the trailer and a full fuel tank.
14		Model and serial number label: This label shows the model name and the serial number for the heat exchanger on your machine.

Ref.	Label	Label Text
15		<p>A nameplate listing the model number, item number, revision number, and serial number is attached to each unit. Please record the information found on this plate so it will be available should the nameplate become lost or damaged. When ordering parts or requesting service information, you will always be asked to specify the model number, item number, revision number, and serial number of the unit.</p>
16		<p>Schematic label. This label, located behind the control panel, shows the electrical schematic for the machine.</p>
17		<p>Installation and instruction label. This label shows installation and operation instructions for the unit.</p>
18		<p>Center of gravity.</p>

3 Operation

3.1 System Description

The Cub series Air Heater machines are indirect-fired air heaters. The Cub series Air Heater machines incorporate aluminized steel shells and heat exchangers. The machines run on three fuel options: diesel, Kerosene, or winter blend diesel (winter blend diesel is treated with anti-gelling conditioners for use in cold weather). The fuel is consumed in a closed combustion chamber. The exhaust gasses must be vented outdoors through a vent pipe. The clean, dry hot air is recirculated by means of an enclosed blower.

The Cub series Air Heater machines are intended to heat air on construction sites and in other rugged environments. Do not use the machines for any other purpose.



3.2 Installing the Lift Brackets

See graphic ghi_gr005931

Before attempting to lift the Cub 200 and 300 models, the lift brackets must be installed.


3.2.1 Remove the machine from the crate.

3.2.2 Install the four lift brackets (a) as shown using the supplied bolts and washers.



ghi_gr005931

3.3 System Component Locations



wcghi_gr004011

Ref	Component	Ref	Component
1	Fuel tank	2	Air outlet
3	Flue collar (vent)	4	Burner access panel
5	Handle (and base)	6	Control panel
7	Blower	8	Fuel oil filter
9	Lifting device	10	Duct adapter

3.4 Mounting the Handle and Base Assembly


See graphics: *wcghi_003991* and *ghi_gr005319*

The Cub series Air Heater machines are shipped partially assembled. Before operating either machine, use the following procedure to mount the handles and base assembly. This assembly includes the handle, base support, and wheels with axles.


Note: *There are pre-drilled bolt holes for all the components installed within this procedure.*

Note: *The Cub 300 HD requires that only the handle be attached. Refer to the procedure below to install the handle.*

- 3.4.1 Attach the axles to the sides of the fuel tank using the supplied bolts and washers.
- 3.4.2 Install the wheels using a rubber mallet to secure them to the axle ends.
- 3.4.3 Attach the base support to the rear of the fuel tank using the supplied bolts and washers.
- 3.4.4 Attach the handle to the machine using the supplied bolts (and washers, if applicable).



wcghi_003991



ghi_gr005319

3.5 Machine Location

The Air Heater machines may be located outdoors or in any environment that requires heating. When locating a machine within the area to be heated, the exhaust gases must be vented to the outdoors.

The machines must be installed:

- By qualified personnel who have read and understood all supplied instructions.
- On a flat, firm surface.
- With the following minimum clearances:
 - 3.05 m (10 ft.) to front.
 - 0.61 m (2 ft.) to rear.
 - 0.61 m (2 ft.) to sides.
 - 1.52 m (5 ft.) to top.
 - 0.915 m (3 ft.) to flue pipe.

3.6 Suggested Venting


See Graphic: *wcghi_gr003990*



Exhaust gas from this machine CAN KILL YOU IN MINUTES. The exhaust contains carbon monoxide, a deadly poison you can not see or smell. This machine must be properly vented to reduce the risk of carbon monoxide poisoning.

When installing vents:

- Adhere to all local and national codes.
- Consult all appropriate governing bodies or local contractor for venting and fresh air requirements.
- Place the machine in a manner that avoids excessive vent bends (elbows), and long horizontal runs.
- Keep air inlets and outlets free from obstruction.
- Route the venting pipes in a manner that avoids any flammable material.
- Route the venting pipes in a manner that avoids contact with humans.



wcghi_gr003990

**WARNING**

Exhaust gas from this machine **CAN KILL YOU IN MINUTES**. The exhaust contains carbon monoxide, a deadly poison you can not see or smell. This machine must be properly vented to reduce the risk of carbon monoxide poisoning.

- The above venting diagram shows suggested venting layouts only. Consult all appropriate governing bodies or local contractor for venting and fresh air requirements.

3.7 Connecting Power to the Machine



Fire and electric shock hazard. High voltage can cause severe injury or death. This unit must be electrically grounded. Do NOT use adapters.


The Air Heater machines come equipped with power cords. Connect the power cord to a grounded outlet rated for 115V, 60 Hz, 15A.

3.8 Preliminary Checks

Before starting the machine, check the following:

- Fuel supply on diesel burning machines. See *Fuel Blend Guide*.
- Position of power switch. It must be in the Off ("O") position.
- Power supply. The machine must be connected to a 115V 60Hz power supply.
- Machine location. Ensure that the machine is properly located according to the *Machine Location* guidelines in this manual.
- Remote thermostat connection. If the remote thermostat will not be used, the remote thermostat receptacle cover must be installed.

3.9 Control Panel



Ref	Component	Function
a	Remote thermostat receptacle	The remote thermostat receptacle (shown with protective cap installed) is used for connecting an optional remote thermostat
b	Burner fault lamp and reset button (dual function).	The dual function burner fault lamp and reset button: <ul style="list-style-type: none"> illuminates red when the burner has faulted. resets the machine when pressed.
c	Power switch	The power switch provides power to the machine.
d	Power cord	The power cord provides a means of connecting the machine to a 115V 60 Hz receptacle.
e	Power indicator lamp	The power indicator lamp illuminates green when the power cord is connected to a 115V 60 Hz receptacle.

3.10 Starting the Machine

3.10.1 Perform the necessary preliminary checks. See section *Preliminary Checks*.

3.10.2 If using the remote thermostat, connect it to the control panel at the remote thermostat receptacle. Place the remote thermostat in the area to be heated. Set it to the desired temperature.

Note: *If the ambient temperature is below 32°F (0°C), it may be necessary to preheat the fuel. See section **Preheating the Fuel Filter and Nozzle Heater**.*

3.10.3 Move the power switch to the On “I” position.

- The blower will turn on immediately.
- The burner will go through a prepurge cycle and then light.
- The burner will continue to fire until the temperature of the space being heated reaches the temperature set by the thermostat. At that time, the burner shuts down but the blower will remain on.
- If not using the remote thermostat, the blower will continue to operate until shutdown.

3.11 Starting the Machine in (Extreme) Cold Weather

In temperatures below 32°F (0°C), it may be necessary to preheat the fuel inside the fuel filter canister. The fuel filter and nozzle contain low-wattage heating elements that are controlled by a thermostat and are specifically designed for this purpose.



Hot surface hazard.

The external surface of the fuel filter may be hot.

- Wear safety gloves when handling the fuel filter.

Note: *Excess heating may increase the need for maintenance. See sections “Replacing the Fuel Filter” and “Replacing the Burner Nozzle”.*

To preheat the fuel, carry out the following procedure.

- 3.11.1 Connect power to the machine. See section *Connecting Power to the Machine*.
- 3.11.2 Wait 20-30 minutes—longer for colder temperatures.
- 3.11.3 Start the machine. See section *Starting the Machine*.

Note: *In extreme wind, the machine may need to be temporarily blocked from the wind in order to start.*

- 3.11.4 If the burner does not start on the first attempt, allow the power-on sequence to cycle again (see 3.10.3).
- 3.11.5 If, after the second power-on sequence completes, the machine will not fire, move the power switch to the off position.
- 3.11.6 Wait another 20-30 minutes and attempt to start the machine again.

3.12 Shutting Down the Machine



WARNING

Electric shock and cutting injury hazard! At temperatures above 104°F (40°C), electric power is available at the supply blower even with the operation mode switch in the OFF position. Always remove all power to the machine before servicing it.

- 3.12.1 Move the power switch to the Off ("O") position.

Note: *The burner will shut down; however, the fan will continue to operate for approximately two minutes to allow the combustion chamber to cool.*

- 3.12.2 When the blower has shut off automatically, disconnect the power supply cord.





- 3.12.3 Disconnect the remote thermostat and re-install the receptacle cover.

3.13 Using the Remote Thermostat

See Graphic: wcghi_gr004009

In order for the machine to function, the remote thermostat **(b)** or the receptacle cover **(a)** must be installed into the control panel. To use the remote thermostat:

- 3.13.1 Plug **(c)** the remote thermostat into the control panel.
- 3.13.2 Set the sensor end within the space to be heated.
- 3.13.3 Adjust the temperature setting with dial **(d)**.



wcghi_gr004009

Notes:

4 Maintenance

4.1 Periodic Maintenance Schedule

	Prior to first seasonal use	As needed or during regular maintenance	Every 1200 hours or yearly
Replace the burner nozzle	■		■
Replace the fuel filter	■		■
Inspect the burner electrodes	■	■	■
Inspect and clean the Cadmium (CAD) cell.		■	
Check the fuel pressure	■	■	
Clean the fan blades and motor	■	■	■
Clean the interior shell	■	■	■
Inspect the flame head	■	■	
Inspect all electrical connections	■	■	■

4.2 Removing and Installing the Burner Assembly

See graphic: *wcghi_gr004015*





Before performing any maintenance on the burner assembly, it must be removed from the machine. To remove or install the burner assembly perform the following procedure:

Removal:

- 4.2.1 Shut down the machine and allow it to cool.
- 4.2.2 Disconnect the power cord from the power source.
- 4.2.3 Remove the two bolts **(a)** and open the access panel.
- 4.2.4 Remove the screw **(d)** to disconnect the ground wire **(c)** from the burner assembly.
- 4.2.5 Rotate the burner assembly **(b)** counter-clockwise and remove it from the flame head and air tube assembly **(e)**.
- 4.2.6 Perform the required maintenance.
Note: *Refer the maintenance procedures in this manual.*
- 4.2.7 Re-install the burner assembly. Refer to the steps below to install the burner assembly.

Installation:

- 4.2.8 Place the burner assembly into the flame head and air tube assembly **(e)**.
- 4.2.9 Rotate the burner assembly clockwise to lock it into place.
- 4.2.10 Install the ground wire **(c)** using the screw **(d)**.
- 4.2.11 Close the access panel and re-install the two bolts **(a)** that secure the panel.



wcghi_gr004015

4.3 Replacing the Burner Nozzle

See Graphic: *wcghi_gr004016*


To replace the burner nozzle, carry out the following procedure:

Removal:

- 4.3.1 Remove the burner. See section *Removing and Installing the Burner Assembly*.
- 4.3.2 Place an adjustable wrench on the large fitting **(1)** on the nozzle base **(3)**.
- 4.3.3 Place another adjustable wrench on the nozzle **(2)**.
- 4.3.4 Rotate the nozzle counter-clockwise and remove it from the assembly.

Installation:

- 4.3.5 Install the new nozzle **(2)** onto the nozzle base **(3)**.
- 4.3.6 Tighten the nozzle **(2)** using an adjustable wrench. Rotate the wrench clockwise.
- 4.3.7 Re-install the burner assembly. See section *Removing and Installing the Burner Assembly*.



wcghi_gr004016

4.4 Replacing the Fuel Filter

See Graphic: *wcghi_gr004019*



CAUTION

Hot surface hazard.

The external surface of the fuel filter may be hot.

- Allow the machine to cool before servicing.
- Wear safety gloves.



WARNING

Hot fluids.

The fuel inside the filter canister may be hot.

- Allow the machine to cool before servicing.
- Wear safety glasses.



To replace the fuel filter **(b)**, carry out the following procedure.

Removal:

- 4.4.1 Shut down the machine and allow it to cool.
- 4.4.2 Remove all power from the machine (unplug).
- 4.4.3 Remove the screw **(a)** that secures the cover to the housing.
- 4.4.4 Remove the filter **(b)**.

Installation:

- 4.4.1 Install the new filter **(b)**.
- 4.4.2 Inspect the rubber gasket **(c)** for damage.
- 4.4.3 Install the cover and the screw **(a)**.



wcghi_gr004019


4.5 Inspecting and Aligning the Burner Electrodes

See graphic: *wcghi_gr004020*

To inspect and align the burner electrodes, carry out the following procedure.


Inspection:

- 4.5.1 Remove the burner assembly. See section *Removing and Installing the Burner Assembly*.
- 4.5.2 Inspect the electrodes for the following:
- Wear. Be sure to inspect the ends of the electrodes for pitting. Replace any worn electrodes. See section "Replacement or Alignment".
 - Straightness. Replace any bent or broken electrodes. See section "Replacement or Alignment".
 - Corrosion and/or cleanliness. Clean the electrodes with a soft dry cloth or replace if necessary. See section "Replacement or Alignment".
 - Correct alignment. Align the electrodes as shown.



Replacement or Alignment:

- 4.5.3 Loosen the screw (1).
- 4.5.4 Align the electrode as shown or remove if necessary.
- 4.5.5 Install a new electrode if necessary.
- 4.5.6 Tighten the screw (1).
- 4.5.7 Verify the electrodes are correctly aligned.
- 4.5.8 Reinstall the burner. See section *Removing and Installing the Burner Assembly*.



wcghi_gr004020


4.6 Inspecting and Cleaning the Cadmium (CAD) Cell

See Graphic: *wcghi_gr004021*

To inspect and clean the CAD cell, carry out the following procedure.

- 4.6.1 Remove the burner assembly. See section *Removing and Installing the Burner Assembly*.
- 4.6.2 Twist and pull out the plastic protective holder **(1)** off the base of the burner assembly. The CAD cell is inside this plastic holder.
- 4.6.3 Inspect the CAD cell for the following:
 - Cleanliness. Be sure the cell is free of debris or soot.
- 4.6.4 Clean the cell if necessary.

NOTICE: Do NOT use solvents or liquids to clean the CAD cell. Use a soft dry cloth to clean the CAD cell.
- 4.6.5 Reinstall the plastic protective holder **(1)** onto the base of the burner assembly.
- 4.6.6 Reinstall the burner assembly. See section *Removing and Installing the Burner Assembly*.



wcghi_gr004021

4.7 Checking and Adjusting the Fuel Pressure

See Graphic: *wcghi_gr004025*





To check the fuel pressure a pressure gauge is needed. To check and/or adjust the fuel pressure, carry out the following procedure:

- 4.7.1 Shut down the machine and allow it to cool.
- 4.7.2 Disconnect the power cord from the power source.
- 4.7.3 Remove the two bolts **(a)** and open the access panel.
- 4.7.4 Remove the threaded plug **(b)** from the pressure test port using an allen wrench. Set the plug in a safe location to be re-installed later.
- 4.7.5 Install a pressure gauge with adapter in the pressure test port **(c)**.
- 4.7.6 Start the machine. See section *Starting the Machine*.
- 4.7.7 With the machine running, verify the fuel pressure setting. For the correct settings, refer to the *Technical Data* charts in this manual.
- 4.7.8 Shut down the machine. See section *Shutting Down the Machine*.
- 4.7.9 Adjust the fuel pressure if necessary using the adjusting screw **(e)** and re-check the settings. Repeat steps 6-8 to re-check the settings.



Do not adjust the fuel pressure to a setting outside the safe operational parameters.

- 4.7.10 Remove the pressure gauge **(d)** from the pressure test port **(c)**.
- 4.7.11 Re-install the threaded plug **(b)** into the pressure test port **(c)**.
- 4.7.12 Close the access panel and re-install the two bolts **(a)** that secure the panel.



wcghi_gr004025

4.8 Cleaning the Fan Blades and Motor

See graphic: *wcghi_gr004030*

To clean the fan blades and motor, carry out the following procedure:

- 4.8.1 Shut down the machine and allow it to cool.
- 4.8.2 Disconnect the power cord from the power source.
- 4.8.3 Remove the fan guard. There are four screws that secure the guard.
- 4.8.4 Remove the six bolts that secure the top portion of the shell.
- 4.8.5 Remove the top shell to access the interior of the machine.
- 4.8.6 Inspect and, if necessary, clean the motor using compressed air.
- 4.8.7 Clean the fan blades using a brush.
- 4.8.8 Re-install the top shell using the six bolts.
- 4.8.9 Re-install the fan guard.



wcghi_gr004030

4.9 Cleaning the Interior Shell

See graphic: *wcghi_gr004029*

To clean the interior shell, carry out the following procedure:

- 4.9.1 Shut down the machine and allow it to cool.
- 4.9.2 Disconnect the power cord from the power source.
- 4.9.3 Remove the fan guard. There are four screws that secure the guard.
- 4.9.4 Remove the six bolts that secure the top portion of the shell.
- 4.9.5 Remove the top shell to access the interior of the machine.
- 4.9.6 Inspect and, if necessary, clean the interior shell using compressed air.
- 4.9.7 Re-install the top shell using the six bolts.
- 4.9.8 Re-install the fan guard.





wcghi_gr004029

4.10 Inspecting the Flame Head

See Graphic: *wcghi_gr004028*

To inspect the flame head, carry out the following procedure:

- 4.10.1 Remove the burner assembly. See section *Removing and Installing the Burner Assembly*.
- 4.10.2 Mark the location of the air lock sleeve **(c)** with a pencil.
- 4.10.3 Loosen the wing nut **(b)**.
- 4.10.4 Loosen the four screws **(a)** that secure the flame head **(d)**.
- 4.10.5 Turn the flame head **(d)** counter-clockwise and remove.
- 4.10.6 Inspect the flame head **(d)** for the following:
 - Wear. Replace if necessary.
 - Cleanliness. Clean the flame head if necessary.
 - Thermal stress. Replace if necessary.
- 4.10.7 Re-install the flame head **(d)**.
- 4.10.8 Position the air lock sleeve **(c)** at the marked location.
- 4.10.9 Tighten the wing nut **(b)**.
- 4.10.10 Tighten the four screws **(a)**.
- 4.10.11 Re-install the burner assembly. See section *Removing and Installing the Burner Assembly*.



wcghi_gr004028

4.11 Inspecting the Electrical Connections

After disconnecting the power cord, check all electrical connections for the following:

- Proper connections. Be sure that all connections are complete and tight.
- Corrosion. Clean or replace if necessary.
- Damaged wires/connectors. Replace if necessary.
- Proper ground.

4.12 Fuel Blend Guide

Fuel Blend Guide	
Temperature Range	Fuel Blend
15° to 30°F	80% #2 : 20% #1
0° to 15°F	70% #2 : 30% #1
–15° to 0°F	50% #2 : 50% #1
below –15°F	30% #2 : 70% #1

4.13 Transporting

Cub series Air Heater machines must be supported by use of blocks during transport. **NOTICE:** DO NOT strap or chain down the unit with the foot or wheels in contact with the transporter.

- Openings or the entire unit should be covered during transport to avoid road debris and clutter.
- Take care when placing straps on areas which are painted red. Use corner protectors and never use chains.
- Excessive loading on the foot, wheels, and axle will cause permanent damage
- The foot and wheels are for moving by hand and for parking only.
- This unit is not designed to be towed with any vehicle.
- All venting external to the machine must be removed prior to transporting.
- Only qualified riggers should attempt aerial lifting.

4.14 List of Abbreviations

Amp	ampere (unit of electrical current)
asl	above sea level
BTU	British Thermal Unit
°C	Celsius (metric unit of temperature)
°F	Fahrenheit (unit of temperature)
ft ²	square foot/square feet (measurement of area)
ft.lbs.	foot pounds (unit of torque)
gph	gallons per hour (unit of liquid flow)
GFI	Ground Fault Interrupt(er) (protection device)
Hz	Hertz (unit of frequency)
ID	inner diameter
in.	inch
kg	kilogram
kilo-cal	kilo-calorie (1000 calories) (metric unit of heat energy)
kPa	kilo-Pascals (metric unit of pressure)
kW	kilo-Watt (unit of electrical power)
lb.	pound
m	meter
mm	millimeter (1/1000 of a meter)
psig	pounds per square inch gauge (unit of pressure)
VAC	Volts, Alternating Current
VDC	Volts, Direct Current
VFD	Variable Frequency Drive
HTF	Heat Transfer Fluid


4.15 Troubleshooting

Note: The following symptoms and remedies are some of the more common issues that have arisen during the history of these machines. These do not represent all the possibilities. If you need advanced troubleshooting assistance, please contact Wacker Neuson Product Support.

Symptom	Possible Causes	Remedy
The burner does not start	<ul style="list-style-type: none"> • The remote thermostat or thermostat plug is not inserted correctly. • Faulty cable or power supply • The over temperature limit has tripped • The burner is in lock-out mode. 	<ul style="list-style-type: none"> • Insert the remote thermostat or thermostat plug. • Check cable and power supply • Press the reset button.
The burner starts, the flame does not ignite, the unit locks out	<ul style="list-style-type: none"> • No fuel • Worn burner nozzle • Faulty electrodes • Cad cell detecting external light. • Cad cell defective • Burner control defective 	<ul style="list-style-type: none"> • Fill fuel tank • Replace burner nozzle • Replace electrodes • Check the Cad cell enclosure
The burner starts, flame ignites, but the unit locks out	<ul style="list-style-type: none"> • Incorrect fuel pressure • Worn burner nozzle • Incorrect air lock setting • Cad cell defective • Burner control defective 	<ul style="list-style-type: none"> • Increase fuel pressure • Replace burner nozzle • Re-adjust air lock setting
The burner ignites but the performance is poor	<ul style="list-style-type: none"> • Worn burner nozzle • Clogged fuel filter • Air leaks in the fuel lines • Insufficient oil pressure 	<ul style="list-style-type: none"> • Replace burner nozzle • Replace the fuel filter • Inspect the lines for leaks; replace if necessary
Black smoke from vent pipe	<ul style="list-style-type: none"> • Insufficient combustion air • Insufficient ventilation air 	<ul style="list-style-type: none"> • Remove any obstructions from the air inlet and outlet areas.
The machine stops due to pressure switch fault	<ul style="list-style-type: none"> • Overheat condition • Faulty pressure switch 	<ul style="list-style-type: none"> • Contact Wacker Neuson Product Support


Notes:

4.16 Cub 200/300 Wiring Schematic



ghi_gr005935

4.17 Cub 300 HD Wiring Schematic



ghi_gr005936

4.18 Schematic Legend

Ref.	Description	Ref.	Description
a	Fuel solenoid valve	i	Pressure switch
b	Photo cell	j	Push button reset light
c	Fuse	k	Heated filter
d	ON-OFF switch	l	Relay
e	Motor	m	Temperature limit control
f	Power light	n	Capacitor
g	Remote thermostat	o	Air temperature switch
h	Transformer	p	Nozzle preheater

5 Technical Data

5.1 Machine Technical Data

Item Number Model		0620204 0620262 Cub 200	0620233 Cub 300	0620253 Cub 300 HD
	Units			
Heat input	BTU/hr	180,000	289,000	289,000
Heat output	BTU/hr	147,000	232,000	232,000
Air flow	cfm	1300	2600	2600
Fuel consumption	L (gal)/hr	4.85 (1.28)	7.72 (2.04)	7.72 (2.04)
Fuel nozzle size	gal/hr-deg	1.00-60	1.5-80	1.35-80
Efficiency	%	81.5	80	80
Noise level at 2 m	dB (A)	73	71	73.9 (at 3 m)
Power requirement	VAC/Hz	115/60	115/60	115/60
Electrical current	Ampere	7	12	14
Weight (no fuel)	kg (lb)	79.4 (175)	116.1 (256)	264(583)
Height	cm (in.)	78.7 (31)	116.8 (46)	130.8(51.5)
Length	cm (in.)	139.7 (55)	172.7 (68)	228.3(89.9)
Width	cm (in.)	61 (24)	69.9 (27.5)	97.5(38.4)
Flue diameter	cm (in.)	15.2 (6)	15.2 (6)	15.2 (6)
Fuel tank capacity	L (gal)	100 (26.42)	138.9 (36.7)	232.8(61.5)
Fuel pressure	psi	175	175	218
Air lock setting	number	2	3	5

